

ATTACHMENT TO CEMENTING REPORT FOR N.E. AVALON "36" STATE #1
MEWBOURNE OIL CO. 36-20-27
12-08-98

Tag bottom @ 1112' w/ 1" pipe. PUH to 1088'. Mix and pump 100sx "C" w/ 3% CaCl_2 . WOC.
Tag TOC @ 1023'. Mix and pump 100sx "C" w/ 3% CaCl_2 . WOC.
Tag TOC @ 968'. Mix and pump 100sx "C" w/ 3% CaCl_2 . WOC.
Tag TOC @ 968'. Mix and pump 50sx "C" w/ 7% CaCl_2 . WOC.
Tag TOC @ 968'. Pour P-Gravel in hole. Build a 7' bridge. Mix and pump 50sx "C" w/ 7% CaCl_2 . WOC.
Tag TOC @ 845'. Mix and pump 50sx "C" w/ 7% CaCl_2 . WOC.
Tag TOC @ 820'. Pour P-Gravel in hole. Build a 10' bridge. PUH to 785. Mix and pump 100sx "C". First 50sx neat, second 50sx (or tail) w/ 7% CaCl_2 . WOC.
Tag TOC @ 695'. Mix and pump 50sx "C" 16# PPG & 50sx "C" w/ 7% CaCl_2 . WOC.
Tag TOC @ 755'. Pour P-Gravel in hole, no gain. Mix and pump 25sx "C" w/ 7% CaCl_2 . WOC.
Tag TOC @ 785'. Mix and pump 25sx "C" w/ 7% CaCl_2 . WOC.
Tag TOC @ 692'. Mix and pump 50sx "C" w/ 7% CaCl_2 . WOC.
Tag TOC @ 421'. Mix and pump 50sx "C" w/ 7% CaCl_2 . WOC.
Tag TOC @ 330'. Mix and pump 100sx "C" w/ 4% CaCl_2 . WOC.
Tag TOC @ 330'. Mix and pump 100sx "C" w/ 4% CaCl_2 . WOC.
Tag TOC @ 160'. Mix and pump 50sx "C" w/ 4% CaCl_2 . Circ. 10sx cmt. to pit.