

15. Attempt to flow well back well to frac tank. If well will not kick-off, RU swabbing equipment and kick well off. Use caution when swabbing well and take small bites of fluid until well starts to unload.
16. Once well flowing, notify field personnel & turn well to sales.
17. RDMO PU.