

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANITARY	☒
FILE	☒
U.S.G.S.	☒
LAND OFFICE	☒
OPERATOR	☒

NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED

SEP 27 1984

O. C. D.

ARTESIA OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

30-015-0 2490

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PERMISSION TO DRILL OR TO REOPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT TO DRILL OR REOPEN FOR SUCH PURPOSES.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐

Name of Operator
Austin Gas Purchasing ✓

Address of Operator
Box 159, Stafford Kansas 67578

Location of Well
UNIT LETTER 0, 330 FEET FROM THE South LINE AND 1650 FEET FROM
THE East LINE, SECTION 12 TOWNSHIP 24S RANGE 28E N.M.P.M.

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

7. Unit Agreement Name
Malaga ✓

8. Term of Lease Name
10

9. Well No.
1

10. Field and Pool, or Wildcat
Malaga

12. County
Eddy

15. Elevation (Show whether DF, RT, GR, etc.)
2946 GL

6. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☒
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	OTHER ☐

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 9/7/84
- spot 25 sxs. on bottom @ 2650; tagged cement plug at 2490.
 - Pulled tubing to 1450 ft. set packer tested to 500 # - 5 min. ok. Perforated at 1525. Run 4 joints - 1575 ft. with tubing pumped 25 sxs. top cement 1415 ft.
 - Pulled tubing; run back 1 jt. set packer. pumped 50 sxs. cement 13 bbls. sully & 1 bbl. flush. Waited 1 1/2 hrs. run packer by perf. at 225 ft. no cement; set packer at 300 ft. and tested. Down 500 #, 5 min. ok. Pulled tubing left a jt. in hole pumped 50 sacks, getting good return. S.D.F.N. Run packer in hole cement down 10 or 12" from top; filled pipe with dry cement. Install dry hole marker.

clean up location.

Post ID-2
10-5-84
p4A

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

CED. [Signature] TITLE President DATE 9/18/84

APPROVED BY [Signature] TITLE Geologist DATE 10-10-84

CONDITIONS OF APPROVAL, IF ANY: