


## **Mallon Oil Company**

Procedure to P&A Allied 21 Com. No. 1 – Continued.  
Attachment to Sundry Notice Dated 5-3-2000

7. Pull up and spot a 100' plug from 425' up to 325'. This plug covers the 13 3/8" casing shoe and covers the fresh water zones.
8. Pull up and spot a 50' surface plug.
9. RDPU and BOP. Clean location and cut off all anchors. Set a P & A Marker and do surface reclamation as per requirements.

Note: All cement plugs will be based on log caliper or a large hole diameter. There will be salt gel mud between all plugs. Plugs to be tagged by BLM requirements.

Attachment – Well bore diagram.

Signed  Title Production Superintendent Date: 5-03-2000

RECEIVED

MAY 09 2000

ELM  
ROSWELL, NM