	l)
Submit 3 Copies To Appropriate Districts	Form C-103 A Revised March 25, 1999
Office State Of New Mexico The	Revised March 25, 1999
1625 N. French Drive., Hobbs, NM 88240	Vell API No.
	30-015-20331 5. Indicate Type Of Lease
B11 S. First, Artesia, NM 88210 $O_{CD}^{TECEIVED}$ 42040 South Pacheco District III $ARTESIA$ Santa Fe, NM 87505	State T Fee
1000 Rio Brazos Rd., Aztec, NM 67410	
District IV	6. State Oil and Gas Lease No.
2040 South Pacheco, Santa Fe, NM \$2505 E: 314	7. Lease Name Or Unit Agreement
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A	Name:
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	Tracy
1. Type Of Well: Oil Well Gas Well Other X Brine	Hacy
Name Of Operator Ray Westall Operating	8. Well No. 003
Address Of Operator	9. Pool Name Or Wildcat
P.O. Box 4 - Loco Hills, New Mexico 88255	
Well Location	
Unit Letter M : 560' Feet From The South Line And 610' Feet From The West	Line
Section 03 Township 22S Range 21E NMPM County Eddy	
Section 03 Township 22S Range 21E NMPM County E00y 10. Elevation (Show whether DR, RKB, RT, GR, ect.)	
11. Check The Appropriate Box To Indicate Nature Of Notice, Report Or Other D.	
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:	
Remedial Work Plug And Abandon Remedial Work Alter Ca	sing
Temporarily Abandon Change Plans Commence Drilling OPNS. Plug an	d Abandonment
Pull Or Alter Casing Multiple Completion Casing Test and Cement Job	
Other Other:	
12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimates and give pertinent dates are stated as a state and give pertinent dates are stated as a sta	nated date of starting any
proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or reco	mpletion.
02/13/01 Pull tubing, tag bottom and set CIBP at 981'.	
Perf 601' Pressure test casing to 400# - held. Perf 270' Pressure test casing to 400# - held.	
Run tubing to 979' pumped 14.5 bbls cement top 400'.	
Bring tubbing to 450' pumped 20 bbls cement.	
Displace all fluid in hole until circulate.	
Good cement at surface.	
Pull out of hole, load hole with cement. Load cement between 5 1/2" and 8 5/8" casing.	
Total Cement: 150 sxs	
02/14/02 Install marker and clean location.	
I hereby certify that the information above is true and complete to the best of my knowledge and belief.	02/27/02
Signature Signature A latheurs Title Production Secretary	Date 02/27/02
Type Or Print Name: Rene Mathews Telephon	e No. (505) 677-2370
Type Or Print Name: Rene Mathews Telephon (THIS SPACE FOR STATE USE) 000 0 0	
(THIS SPACE FOR STATE USE)	• NO. (505) 677-2370 APR 4 2002
(THIS SPACE FOR STATE USE) APPROVED BY Title Title	
(THIS SPACE FOR STATE USE)	