

4 Logging Procedure -
Gene Lane - will submit 6103 5-5-94

Tag 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100
Tag A No. 1 C 18 23 27
2 Carlsbad Marrow - Eddy Co
1 BP equiv at 11,470
35 cement at 11,470

(2) Set BP at 10,626 + 35'
cement - A to K

(3) Set CIBP at 9538 + 35'
(Top Penn)

4) Set CIBP at 7800 + 35'
(Top Wolfcamp)

Tag 5) Cut <sg at ± 7900 - 170 ft
50' in + 50' out of Stub.

6) 100' Plug at 5518 - 5243
(8 5/8" + Top of Zone 5)

Tag 7) Cut 25/8 at ± 2150
Plug 50' in stub (± 2200 to 1717) -
(cover stub, ^{Top} Delaware Base Salt)

Tag 8) ~~100'~~ 100' Plug 420 to 320
(13 3/8" at 370')
a) < ...