

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

U. S. C.
LAND OFFICE

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>	
1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER DRY HOLE	7. Unit Agreement Name
2. Name of Operator	WILDCAT-DELAWARE
BABER WELL SERVICING CO.	8. Farm or Lease Name
3. Address of Operator	TOM LEE
BOX 1772, HOBBS, NEW MEXICO 88240	9. Well No.
4. Location of Well	#1
UNIT LETTER C 1230 FEET FROM THE N LINE AND 1980 FEET FROM	10. Field and Pool, or Wildcat
THE W LINE, SECTION 29 TOWNSHIP 22-S RANGE 27-E NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
3552 RT	EDDY

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
-------------------------	-----------------------

PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>
---	--

REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
--	--

16. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Moved in - rigged up.
2. Ran tubing to 3250'
3. Set 100' plug - 40 sx. cement to 3100'
4. Pulled on 9-5/8" and cut off at free point *measured 1494'*
5. Pulled 9-5/8" and set plug @ 1550' (60 sx.)
6. Set 100' plug @ 310'-410' (100 sx.)
7. Set 10 Sx. plug @ surface.
8. Weld 13-3/8" plate inside surface pipe
9. Rig down. Clean location. Move off.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Sam Rabe* TITLE PRESIDENT DATE 2/18/77

APPROVED BY *[Signature]* TITLE OIL AND GAS INSPECTOR DATE MAR 3 1 1977

CONDITIONS OF APPROVAL, IF ANY: