

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 87240  
District II  
811 South First, Artesia, NM 87210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised March 25, 1999

OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, NM 87505

WELL API NO.  
**30-015-20607**

5. Indicate Type of Lease  
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.  
—

7. Lease Name or Unit Agreement Name:  
**CEDAR CANYON**

8. Well No.  
**1**

9. Pool name or Wildcat  
**CEDAR CANYON DELAWARE**

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator  
**BK EXPLORATION CORP.** OGRID **002433**

3. Address of Operator  
**810 S CINCINNATI STE 208 TULSA OK 74119**

4. Well Location  
Unit Letter **P** : **770** feet from the **S** line and **770** feet from the **E** line  
Section **9** Township **24-S** Range **29-E** NMPM County **EDDY**

10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
**2941' GR 2969' KB**

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:  
REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

PLUG AND ABANDON AS FOLLOWS: (SEE ATTACHED WELLBORE DIAGRAM)

1. RUPU. INSTALL BOP. RELEASE TBG. FROM MOD. 'D' PERMANENT PKR. @ 5467'.  
PULL TBG. OUT.
2. BY WIRELINE, DUMP CMT. ON MOD. 'D' PKR. SET 9 5/8" CIBP @ 4500'. DUMP CMT. ON CIBP. & 35' cement on CIBP. TAG
3. WITH TBG., SET CMT. PLUGS @ 2872-2972', 600-700', and 0-50'.  
PUMP AND SPOT GELLED BRINE BETWEEN CMT. PLUGS.
4. REMOVE BOP. RDPV. INSTALL P+A MARKER.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Brad D Burks TITLE PRESIDENT DATE 10-11-99

Type or print name BRAD D. BURKS 918-582-3855 Telephone No.  
(This space for State use)

APPROVED BY Steve Stillfield TITLE Field Rep. II DATE 10/26/99  
Conditions of approval, if any:

\* Perforate 9 5/8" casing @ 200'. Squeeze 100' cement plug  
inside & outside casing. TAG

\* Notify NMOC to witness Operations