

Calvani Com

Flush: 2000 gal fresh water

10 gal/1000 gal WG-11 (gelling agent)

1 gal/1000 gal LOSURF-300 (surfactant)

500 scf/bbl N<sub>2</sub> (nitrogen)

10. RD acid company. Turn well to flare pit and flow back treatment fluids.

11. Flow test well to determine facility needs.

12. Turn well to system and perform regulatory test.