

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

NM OIL CONS COMMISSION

Drawer DD
Artesia, NM

FORM APPROVED
Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

RECEIVED

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Phillips Petroleum Company

3. Address and Telephone No.

4001 Penbrook St., Odessa, Texas 79762

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit G, 1980' FNL & 1980' FEL of Section 11, T-22-S, R-30-E

5. Lease Designation and Serial No.

NM-0479142

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

James E Fed. No. 1

9. API Well No.

30-015-20996

10. Field and Pool, or Exploratory Area

Cabin Lake (Delaware)

11. County or Parish, State

Eddy, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other Temporarily Abandon

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

6/1/94 Rig up and ND wellhead and install BOP. WIH with wireline to check for fill. found 50' of fill on top of RBP at 5800'. WIH with 2-7/8" workstring and cleaned out fill from 5750' to 5800'. Retrieve RBP. POOH with RBP and tubing.

6/2/94 Pick up 5-1/2" CIBP on 2-7/8" tubing and WIH. Set CIBP at 5600'. Test casing and CIBP to 500# for 30 minutes. BLM was notified prior to test. POOH with 2-7/8" tubing. Load 5-1/2" casing after pulling tubing. Remove BOP and install wellhead.

Casing Test

J. Lara
- 6 1994

RECEIVED
JUN 9 10 54 AM '94
CARLE AREA

* This Approval of Temporary Abandonment Expires

14. I hereby certify that the foregoing is true and correct

Signed J. M. Sanders

Title Supervisor, Reg. Affairs

Date 6/7/94

(This space for Federal or State Office use)

Approved by

Title

Date

Conditions of approval, if any:

TA not approved. Submit justification for status within 30 days.

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side

