

3. Miscellaneous -

- a. Drill string should be stabilized while drilling all hole sizes.
- b. Continuous check on hydraulics should be made.
- c. Run consistometer tests on all cement used for production casing.
- d. After cement job, release pressure immediately if back pressure valves are holding, and begin nipple-up operations.
- e. Pressure test surface casing to 1000 psi before drilling plug; intermediate and production casing and/or liners to 1500 psi.

COMPLETION:

Procedure for completion will be outlined on separately issued Prognosis to Complete.

NOTIFICATION:

1. In case of emergency, please notify the following:

Frank Raley
DISTRICT SUPERINTENDENT

Home -- (915) 586-3859
Office (915) 586-2563

2. Prior to logging, please notify:

W. T. Ford
GEOLOGIST

Home -- (915) 683-3850
Office (915) 682-1272

PREPARED BY:

CHECKED BY:

APPROVED BY:

G. A. Teer