

PROCEDURE WHEN OUT OF THE HOLE

- I. 1) IF the well should start to kick while completely out of the hole.
- 2) Close blind rams, all valves next to spool, and all chokes, shutting well in completely.
- 3) Contact Company Representative and Rig Superintendent immediately. DO NOT leave the rig floor. Send a crewman if necessary.
- 4) Read and record casing pressure at 5 minute intervals.
- 5) Start raising mud weight of entire surface system.
- 6) Keep well shut in while waiting for further instructions.