DISTRIBUTION SANTA FE / NEW MEXICO OIL CONSERVATION COMMISSION	Form C-103
SANTA FE I NEW MEXICO OIL CONSERVATION COMMISSION	Supersedes Old - C-102 and C-103
	Effective 1-1-65
FILE	
U.S.G.S. RECEIVED	State X Fee
LAND OFFICE	State A Fee 5. State Oil & Gas Lease No.
DEC 2 0 1979	K-6440 ·
SUNDRY NOTICES AND REPORTS ON WELLS	
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERD TO CESEMPOIR. 1. OIL GAS DDV HOTE	
ARTESIA OFFICE	7. Unit Agreement Name
WELL DAY HOLE	
2. Name of Operator	8. Farm or Lease Name
JOE DON COOK	EL PASO STATE
3. Address of Operator	9. Well No.
P.O. BOX 159, ROSWELL, NM 88201	#1
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER D . 330 FEET FROM THE NORTH LINE AND 330 FEET FROM	WILDCAT DELAWARE
THE WEST LINE, SECTION 16 TOWNSHIP 24-S RANGE 27-E NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	
3188.4' GR	12. County EDDY
Check Appropriate Box To Indicate Nature of Notice, Report or Oth	•
NOTICE OF INTENTION TO: SUBSEQUENT	REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON COMMENCE DRILLING OPNS.	PLUG AND ABANDONMENT
PULL OR ALTER CASING CHANGE PLANS CASING TEST AND CEMENT JQB	
^7HER	
 Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including work) SEE RULE 1703. 	estimated date of starting any proposed
	estimated date of starting any proposed
work) SEE RULE 1903.	
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C	
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED	
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT	
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED	
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT	
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT	
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT	
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT	EMENT PLUG FROM
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT	EMENT PLUG FROM MARKER WILL BE
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT	EMENT PLUG FROM MARKER WILL BE
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT	EMENT PLUG FROM MARKER WILL BE
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT 35 SX Plug @ 220° Woc Tayged @ 2155 75 SX 1' @ 2145	EMENT PLUG FROM MARKER WILL BE
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' CO 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT 35 SX Plug @ 3200 woc staged @ 2155 75 5X 1' @ 2145 50 5X '' @ 1035-1209	EMENT PLUG FROM MARKER WILL BE
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' CO 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT 35 SX Plug @ 2200 Woc staged @ 2/55 75 SX '' @ 2/450 taggel @ 1/52	EMENT PLUG FROM MARKER WILL BE
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' C 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT 35 SX Plug @ 3200 Woc Tagged @ 2155 75 SX '' @ 2145 50 SX '' @ 1035-1209	EMENT PLUG FROM MARKER WILL BE
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' CO 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT 35 SX Plug @ 2200 Woc stagged @ 2155 75 SX " @ 2145 50 SX " @ 1035-1209 75 SX @ 450 Taggel @ 152 10 SX @ surface w/marker.	EMENT PLUG FROM MARKER WILL BE
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' CO 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT 35 SX Plug @ 3200 woc stagged @ 2/55 15 SX '' @ 2/45 50 SX '' @ 1035-/209 75 SX '' @ 450 Taggel @ 152	EMENT PLUG FROM MARKER WILL BE
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' CO 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT 35 SX Plug @ 3200 woc staged @ 2155 75 5x @ 1035-1209 75 5x @ 450 taggel @ 152 10 5x @ surface w/marker.	MARKER WILL BE PIT LEVEL.
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' CO 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT 35 SX Plug @ 3200 woc staged @ 2155 75 5x " @ 2145 50 5x " @ 1035-1209 75 5x @ 450 taged @ 152 10 5x @ surface w/marker.	EMENT PLUG FROM MARKER WILL BE
SET A 100' CEMENT PLUG FROM 2200-2100' AND AT 100' CO 700-600 IN THE RUSTLER FORMATION. 35 SACKS @ 350-450 & TAGGED 35 SACKS PLUG @ BASE OF SALT 35 SACKS PLUG @ TOP OF SALT HOLE LOADED W/MUD A CAP WAS WELDED ON TOP OF THE SURFACE PIPE AND A 4' ERECTED. LOCATION WILL BE CLEANED OF ALL DEBRIS AT 35 SX Plug @ 3200 woc staged @ 2155 75 5x @ 1035-1209 75 5x @ 450 taggel @ 152 10 5x @ surface w/marker.	MARKER WILL BE PIT LEVEL.

CONDITIONS OF APPROVAL, IF ANY: