

4-4-78

M-7-22-27 C & K Pet, Inc. Canisbad 7 Core #1 Set
Bridge Plug @ 11075 and Cement From 11075 to 11040 FT
Cut $5\frac{1}{2}$ Pipe @ 7620 Pull $5\frac{1}{2}$ Pipe Run $2\frac{7}{8}$ Tubing
and Circulate Hole with Mud - Set 60 Sack Class H
Cement 7670 to 7570 Fill Hole and hot Set 1 hr -
Hole Stayed Full - Set 60 Sack Class H Cement Plug @
6909 to 6809 Pull Tubing and Set 60 Sack Class H
@ 5158 to 5258 - Pull Tubing and Set 60 Sack Class
H Cement @ 3609 to 3509 Hole Standing Full Mud
Set 60 Sack Class H Cement Plug @ 2660 to 2560
hot Set over Nite

Tag Plug @ 2538 Pull Tubing and Set 10
Sack Plug at Surface

Witness By Blowers