

Operator Bass Enterprises
 Well Bass 10' Rod #2
 Unit 15 Section 10 Township 22 Range 28
 API # 30-015-22749

TOPS

Restler	~ 190'
Seaside	~ 475'
Bass Salt	~ 2305'
Delaware	2647'
Bass Spring	5992'
East Frack	9533'
Pima	10500'
S. River	10674'
Chick	11238'
Mountain View	11880'
Mountain View	12070'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.