

Lechuguilla Canyon AJ Federal #

Sec 8-T24S-R24E

-2-

8. Load hole with plugging mud and spot 50 sx Class C cmt plug from 558-668' across the surface csg shoe. POOH with tbg and WOC. Tag plug with tbg and reset if necessary.
9. Spot 15 sx Class C cmt plug at surface.
10. Remove all surface equipment and weld dry hole marker per regulations.

BUREAU OF LAND MGMT.
ROSWELL OFFICE

2000 FEB 16 A 8 58

RECEIVED