

30-015-23031-

M-17-22-27

I & W Inc.

Eugenie #2

5 1/2" csg
D 285'
circ.

< Perf. 335'

* Pull 1" tubing. Rig up 2 7/8" sledge +
squeeze cement to surface inside & outside 2 7/8" casing.

* Run 1" tubing + tag toe in 2 7/8" csg.

Circulate cement to surface.

* Perforate 2 7/8" casing @ 335'.

* Pressure Test 2 7/8" casing.

500 # for 30 minutes. Chart test.

* Displace 10 sk cement Plug to 500'
in 2 7/8" casing. O.C. 24 hours.

2 7/8" csg
D 583'
circ.