

6-30-80 - Trip in hole with 8½" bit. Tag cement at 8893'. Drilling cement to top of 7-5/8" liner at 9532'. Tested liner lap to 1500 psi - O.K.

7-3-80 - Pick up 6½" bit, trip in hole and clean out 7-5/8" liner to float shoe. Tested casing to 1500 psi - O.K. Displaced hole with mud. Drilling ahead.