

Recommended Drilling and Completion Procedure
W. A. Moncrief, Jr.
#2 Baldrige Federal Comm
Page 2

15. Run tubing, 2-3/8" EUE AB modified, and packer.
16. Swab well down.
17. Perforate with 4" casing gun.
18. Production test well.
19. Stimulate well as necessary.
20. Clean up treating fluid.
21. Flow test well.
22. Run C.A.O.F.P. and pressure build up.
23. Connect surface equipment.