BLM & CAMEL D Form approved. Budget Bureau No. 1004-0135 Form 3160-5 UNITED STATES

BUBMIT IN TRIPLICATES

Other instructions on reverse side) (November 1983) Expires August 31, 1985 (Formerly 9-331) 5. LEASE DESIGNATION AND SERIAL NO. BUREAU OF LAND MANAGEMENT NM25954 6. IF INDIAN, ALLOTTEE OR TRIBE NAME SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.

Use "APPLICATION FOR PERMIT—" for such proposals.) 7. UNIT AGREEMENT NAME WELL X OTHER 2. NAME OF OPERATOR 8. FARM OR LEASE NAME Parker & Parsley Petroleum Company Union Federal 3. ADDRESS OF OPERATOR 9. WBLL NO. P.O. Box 3178, Midland, TX 79702 LOCATION OF WELL (Report location clearly and in accordance with any State regularments.\* 10. FIELD AND POOL, OR WILDCAT ACHURACE NIL 1590 FML & 560 FEL Wildent Willow Sce. JAN 26 1987 11. SEC., T., S., M., OR BLK. AND SURVEY OR AREA Sec 33 - T24S- R28E Sec 33 - T24S - R28E O. C. D. 14. PERMIT NO. 15. BLEVATIONS (Show whether DF, RT, CRITERIA, OFFICE 12. COUNTY OR PARISH 13. STATE 29 72 Eddy NM 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF : TEST WATER SHUT-OFF PULL OR ALTER CASING WATER SHUT-OFF REPAIRING WELL FRACTURE TREAT MULTIPLE COMPLETE FRACTURE TREATMENT ALTERING CASING

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and some pertinent to this work.)

SHOOTING OR ACIDIZING

**ABANDONMENT®** 

Set CIBP at 6100' and cap with 35 sacks of cement.

ABANDON\*

CHANGE PLANS

- RIH with tubing. Mix mud using 25# of salt gel per bbls of 10# brine. Circ hole
- 3). Cut 4 1/2" casing at free point & POH.

SHOOT OR ACIDIZA

REPAIR WELL

(Other)

- 4). Spot a 50 sack plug in and out of 4 1/2" casing stub. WOC & tag.
- 5). Spot an 85 sack plug at 2690' - 2500'. WOC & tag (Delaware & 8 5/8" shoe).

X.

- Spot a 40 sack plug at 1100' to 1000' (salt section).
- Spot a 40 sack plug at 530' to 430' (13 3/8" shoe). 7).
- Spot a 15 sack plug at surface. Install dry hole marker.

Top of cement 5600' per Temperature Survey Log.

Approved per Armando Lopez 1-20-87

18. I hereby certify that the foregoing is true and correct		
SIGNED A SOUN	TITLE Agent	DATE 1-15-87
(This space for Federal or State office use)		
Orig: Sgd: Charles S. Dulling APPROVED BY CONDITIONS OF APPROVIES ARE ST	TITLE	DATE 1-2087
CONDITIONS OF APPROVABLE AND		