

Flowed and swabbed 1500 bbls. water w/final oil cut 8%. Still swab testing well as of 12-12-81. Plan to pull RBP at 7002' and run production tubing and rods. Then test well with pumping unit.