

Plug back procedure: Per Larry Brooks
8-27-84

✓ 13 3/8 @ 518 CIRC.
✓ 10 3/4 @ 2330 CIRC.
7 5/8 @ 9128 TOC 1520 ← cut & pull & tag.
5" liner @ 11426-8702

CIBP w/ 35' cmt @ 11100
Plug in liner 9178-9078
Plug @ top of liner 8750-8650
Plug @ 1/2 T.B.S 5730-5830

CIBP C5650
CIBP C5720

10-10-84

Set CIBP @ 5100 ± +35' Cmt.
Set 100' Cmt plug @ 2380-2280'
Set 100' Cmt plug @ 568-468'
10% Cap of marker.
Mud below all plugs.
Call as soon as possible

1980

15-24-27

392-6591 - Hobbs
Shoot @ 1300'

Tag @ 1160

Pumped @ 11am.

1350-1250

#tag ~~1160~~

Shred
 No. 153C
 HASTINGS, MN
 LOS ANGELES-CHICAGO-LOGAN, OH
 MOOREHEAD, TX-LOCUST GROVE, GA
 U.S.A.

ing Tape LB
 BS- 5769
 WBS 8719
 v offcamp 9083
 2mm 10742
 straw 10960
 take 11170
 nonan LS 11798