

14. Drill cement inside 7" casing to the top of liner. Test liner top to 5000#. Squeeze liner top if needed.
15. Drill cement inside liner to float collar. Clean out system and release the drilling rig.
16. The well will be completed after detail evaluation of electric and mud logs.

P. E. Ilavia

P. E. Ilavia
Division Drilling Engineer