

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	☒
FILE	☒
U.S.G.S.	
LAND OFFICE	
OPERATOR	☒

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501
NOV 09 '88

Form C-103
Revised 10-1-7

30-015-25866

5a. Indicate Type of Lease
State ☒ Fee ☐
5. State Oil & Gas Lease No.
NMLG8478

O. C. D.
ARTESIA, OFFICE

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name
2. Name of Operator Santa Fe Energy Operating Partners, L.P.	8. Farm or Lease Name Sterling Silver 32
3. Address of Operator 500 W. Illinois, Suite 500, Midland, TX 79701	9. Well No. 1
4. Location of Well UNIT LETTER J 1980 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 32 TOWNSHIP 23S RANGE 31E NMPM.	10. Field and Pool, or Wildcat Undes. West Sand Dunes Morrow
15. Elevation (Show whether DF, RT, GR, etc.) KB 3395'	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Est Start Date 11-9-88

1. Notify NMOCD.
2. Set CIBP @ 14,000', dump bail 35' cmt on top.
3. Displace hole w/10# BW mud w/25# salt gel/bbl
4. Place 25 sx cmt plug @ 13,210'.
5. Place 25 sx cmt plug @ 11,900'.
6. Place 25 sx cmt plug @ 11,715'.
7. Place 25 sx cmt plug @ 9,030'.
8. Place 25 sx cmt plug @ 6,925'.
9. Shoot off & recover 7" csg @ free point.
10. Place 35 sx cmt plug across 7" csg stub. Tag plug.
11. Place 35 sx cmt plug @ 4180'. Tag plug. Set CIBP above plug.
12. Place 35 sx cmt plug @ 698'.
13. Cut off wellhead 5' below ground level.
14. Place 50' surface plug.
15. Install P&A marker.
16. Clean up location.

Notify NMOCD in sufficient time to witness

Plugging

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Patrick J. Jarama

TITLE Sr. Production Engineer

DATE 11-7-88

Original Signed By
Mike Williams

TITLE

DATE JAN 5 1989