

10. Run temperature survey 12- 18 hrs. after pumping cement to determine TOC. There is no need to run CBL at this time because no pay zones exist in newly cemented portion of well. After WOC for 24 hrs., RIH with 6" bit, DCs and tubing and drill retainer and cement. Test casing to 2000 psi and TOOH.

\*\*\*\*\* COMPLETION PROCEDURE WILL BE ISSUED LATER \*\*\*\*\*

kbc/paulin61.doc