

- 13.) Set a 100' plug from 200' - 300' (30 sacks) cement.
- 14.) Set a 10 sack plug at surface.
- 15.) Cut well head off and weld a 5/16" steel plate on stub and install a dry hole marker.
- 16.) Remove rig anchors and all equipment from lease.

NOV 14 1994

Jfo
11/8/94