

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLICATE  
(Other instructions on  
reverse side)

Budget Bureau No. 1004-0135  
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

LC-069108

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Poker Lake Unit

8. FARM OR LEASE NAME

9. WELL NO.

-71-

10. FIELD AND POOL, OR WILDCAT

Wildcat-Morrow

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 33, T23S, R30E

12. COUNTY OR PARISH

Eddy

13. STATE

N.M.

1. OIL WELL ☐ GAS WELL ☒ OTHER Plug & Abandon

2. NAME OF OPERATOR

Bettis, Boyle & Stovall

3. ADDRESS OF OPERATOR

P. O. Box 1240, Graham, Texas 76046

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)  
At surface

660' FNL & 1980' FWL, NE/4 NW/4 Unit Letter C

14. PERMIT NO.

Dated 3/14/89

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3349.3 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON\*

CHANGE PLANS

(Other) Plug and Abandon Well

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Move-in and rig-up pulling unit and other necessary equipment.
2. Blow well down and load tubing with water.
3. Pull out of hole with present tubing installation.
4. Run and set CIBP at 13,150' KB, dump 50 feet of cement on top.
5. Spot 200 feet of cement from 11,050' to 10,850' KB (top of liner).
6. Set a CIBP @ 8,100' KB (or as required by BLM), cap with 35 feet of cement.
7. Cut and pull 9-5/8" casing at free point.
8. Spot cement plugs as follows:  
Spot a 150 foot cement plug in and out of stub; must tag plug.  
Spot a 100 foot cement plug @ 5,750' KB; must tag plug.  
Spot a 100 foot cement plug @ 3,753' KB; must tag plug.  
Spot a 100 foot cement plug @ 618' KB; must tag plug.  
Spot a 50 foot cement plug @ surface.
9. Cut-off heads and casing string(s); weld a plate on top and install dry hole marker.
10. Clear, level and re-seed location as required by BLM.
11. Rip and re-seed road as required by BLM.

RECEIVED  
MAY 11 11 22 AM '90  
CARLOS J. GARCIA  
AREA IN CHARGE

RECEIVED

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE Agent

DATE May 9, 1990

(This space for Federal or State office use)

APPROVED BY [Signature]

TITLE

DATE 5/15/90

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side