

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

150
op

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

APR 10 1994

WELL API NO. 30-015-26314
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. K-3271
7. Lease Name or Unit Agreement Name James A
8. Well No. 10
9. Pool name or Wildcat Cabin Lake (Delaware)

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Phillips Petroleum Company	
3. Address of Operator 4001 Penbrook St., Odessa, Texas 79762	
4. Well Location Unit Letter <u>N</u> : <u>660</u> Feet From The <u>South</u> Line and <u>2310</u> Feet From The <u>West</u> Line Section <u>2</u> Township <u>22-S</u> Range <u>30-E</u> NMPM <u>Eddy</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3166' GR; 3173.5' KB	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- MIRU DDU. ND wellhead. NU class 2 BOPE.
- RIH & tag fill over RBP at $\pm 5750'$. Clean out if necessary. PU and GIH with tool on 2-7/8" tubing and retrieve RBP at 5750'. COOH with 2-7/8" tubing & RBP.
- GIH with 5-1/2" CIBP on 2-7/8" tubing. Set CIBP at 5600'. Load hole with 2% KCL fresh water w/1% corrosion inhibitor. Test 5-1/2" casing & CIBP to 500 psi for 30 minutes.
- COOH w/2-7/8" tubing & packer. ND BOP. RD DDU.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE L. M. Sanders TITLE Supervisor, Reg. Affairs DATE 4/8/94
TYPE OR PRINT NAME L. M. Sanders TELEPHONE NO. 915/368-1488

(This space for State Use)

SUPERVISOR, DISTRICT II

APR 25 1994

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: