

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED
JUN 27 1991

O. C. D.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-85

clsf
dp

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Well		7. Unit Agreement Name
2. Name of Operator U - Ritch Operating Company		8. Farm or Lease Name Hagerman
3. Address of Operator P.O. Box 10064, Midland, Texas 79702		9. Well No. 1
4. Location of Well UNIT LETTER C, 990' FEET FROM THE North LINE AND 2310' FEET FROM THE West LINE, SECTION 13 TOWNSHIP 23S RANGE 27E NMPM.		10. Field and Pool, or Wildcat Cass Draw (Delaware)
15. Elevation (Show whether DF, RT, GR, etc.) 3080' Ground Level		12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

6/31/91 - We intend to Plug and Abandon the well with the following plugs:

Plug # 1- Cast Iron Bridge Plug @ 2370'. 35' cement on top.
Plug # 2- 100' plug across cutoff. 2125'-1950'. (Tag)
Plug # 3- 100' plug across * 5/8" shoe. 480'-350'. (Tag)
Plug # 4- 10 sx at surface.

We intend on setting CIBP @ 2370', dumping 35' cement on top of CIBP using a dump bailer. Go back in hole and cut off casing at 2000' +. Retrieve casing and follow schedule of plugs. When we are finished, we will install 4' marker to identify well.

We will give you a days notice before we start.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED James M. C. Ritch TITLE Partner - Uritch Operating DATE June 26, 1991
APPROVED BY Johnny Robinson TITLE OIL AND GAS INSPECTOR DATE 7-11-91
CONDITIONS OF APPROVAL, IF ANY: