

5-27-91: Float set @ 10,504'
(cont) 2 jts 5-1/2" 17# N-80
Float collar @ 10,417'
11 jts 5-1/2" 17# N-80
Depth orientation marker @ 9,959'
52 jts 5-1/2" 17# N-80
131 jts 5-1/2" 15.5# K-55
52 jts 5-1/2" 17# N-80

Sandblasted bottom 40 jts, ran 10 centralizers (1 every 3rd jt)
Cemented casing w/ 600 sx C1 "H" + 1% FL-20 & 5% salt. Plug
down at 8:45 a.m. CDT. ND BOP stack and set slip w/ all wt.
Cut off 5-1/2" csg and NU tubing head. Jet and clean all pits.
Rig released at 7:00 p.m. CDT. WOCU.