

Lamb Chop 17 State Com #1  
P&A cont.

- 8/25/94: RIH w/ tbg to 3200', did not tag cmt plug @ 2883'. Pump 75 sx Cl "H" w/ 2% CaCl<sub>2</sub> @ 2883'. Wait 4 hours. RIH to 3200', did not tag cmt. Pumped 75 sx Cl "H" w/ 2% CaCl<sub>2</sub>, pumped 10 bbls fresh water ahead of 12 bbls Cl "H" slurry w/ 2% CaCl<sub>2</sub>. Broke circulation w/ 1 bbl of flush pumped. Total flush 15 bbls.
- 8/26/94: RIH w/ tbg to 3200', did not tag cmt. Spoke to Ray Smith w/ NMOCD. Got permission to set CIBP @ 2701' w/ 45 sx cmt on top of plug. RIH w/ 8-5/8" CIBP to 2701' and set. Setting tool stuck, wait on fishing tools. RIH w/ over shot on tbg to 2701' and fished setting tool. POH.
- 8/27/94: RIH w/ tbg and tag CIBP @ 2701'. Load hole w/ 23 bbls 9.5# mud. Test csg to 500# for 5 min, okay. Spot 45 sx Cl "H" cmt on top of CIBP. POH w/ 12 jts tbg. EOT @ 2300'. Spot 45 sx Cl "H" cmt. POH w/ 24 jts. EOT @ 1600'. Spot 85 sx Cl "H" cmt, covered plug at 1550'. POH w/ 32 jts. EOT @ 480'. Spot 30 sx Cl "H" cmt. POH w/ tbg. ND BOP, cut wellhead off, spot 15 sx Cl "H" plug from 50' to surface. Installed P&A marker.
- 8/30/94: Rig unit down. Dig up dead men & cut off. Remove flowline & fencing. Clean location. Well plugged and abandoned.