

26. RIH with SLM and tag fill. Clean out if necessary. Release packer and retrieve RBP at $\pm 5950'$. Reset RBP to $\pm 7360'$. Set packer and test RBP to 500 psi. Dump 2 sx sand. COOH with 2-7/8" tubing and packer.
27. GIH with 2-7/8", 6.5 lb/ft, EUE 8rd J-55 production tubing. Set tubing at $\pm 5730'$, SN at $\pm 5700'$ and tubing anchor at $\pm 5640'$ in 15,000 lbs tension. Ensure well is static for 30 minutes. Remove BOP and NU wellhead.
28. GIH with pump and rod string. Place on production.