

Mosley Canyon State Unit #1

8/26/93: Lay down 11 jts drill pipe. Wait on more cement. Reset Plug #7 (8-5/8" shoe) at 2800' w/ 35 sx Cl "H". Lay down 12 jts. Set Plug #8 (Surface) w/ 10 sx Cl "H". Circ'd 1 sx cmt. Lay down 2 jts. RD lay down machine & Dowell.

8/27/93: ND stack, cut off wellhead, install dry hole marker, jet and clean all pits. Rig released at 9:00 a.m. MST. Well plugged and abandoned.