

Lambchop "20" Fed Com #1  
Sundry Notice  
Page 2

- 1-24-93: PU bit and BHA. TIH. Tag cmt at 1910'. (Per NMOCD, must  
cont. bond log 8-5/8" to determine if we will be required to circ  
cement on the long string).
- 1-25-93: Finish TIH to 1910'. Tag cement. Drlg 40' cement on top of  
DV tool and drilling DV tool. Test 8-5/8" casing to 1500 psi,  
ok. Drilling cement, float and shoe jt.