

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

FORTSON OIL COMPANY

3. Address and Telephone No.

3325 W. Wadley, Suite 213, Midland, TX 79707 (915) 520-4347

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

330' FSL & 330' FWL Section 25, T22S, R28E, Unit M

FORM APPROVED

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

LC-069159-A

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

BIG EDDY UNIT

8. Well Name and No.

BIG EDDY UNIT #117

9. API Well No.

30-015-27261

10. Field and Pool, or Exploratory Area

E. HERRADURA BEND (Delaware)

11. County or Parish, State

Eddy County, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☒ Conversion to Salt Water
☐ Dispose Water Disposal
- (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- Squeeze off Perforation 2950-72 w/minimum of 50 sks.
- Drill out & test to 1500 psi. Resqueeze if necessary.
- Drill out CIBP @ 3050 & squeeze perfs from 4281-89 w/a minimum of 50 sks.
- Drill out cement & test to 1500 psi. Re-squeeze if necessary.
- Drill out CIBP @ 4325. RIH to CIBP @ 5950. Test casing to 1500 psi.
- Drill out CIBP @ 5950 & RIH to 6130.
- POOH & RIH w/pkr & set at 5912. RIH w/tbg. & prepare to dispose of water in perf from 6012-93.

14. I hereby certify that the foregoing is true and correct

Signed

Title Production Technician

Date 11/3/93

(This space for Federal or State office use)

Approved by

Title

PETROLEUM ENGINEER

Date

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side

Bit. Eddy Lhr. #117
SW 25-22S-28E

State Well

GL 3125

