

WELL SITE DIAGRAM:

A. Attached is a detailed well site diagram showing:

- Drilling rig orientation
- Prevailing wind direction (Southwest)
- Location of briefing areas
- Location of Caution/Danger Signs
- Location of hydrogen sulfide monitors
- Location of wind direction Indicators

HYDROGEN SULFIDE SAFETY EQUIPMENT:

- A. All safety equipment and systems will be installed, tested, and deemed operational when drilling reaches a depth of 500 feet above, or three days prior to penetrating the first zone reasonably expected to contain hydrogen sulfide.
- B. During drilling operations, a flare line will be routed from the BOP manifold to the reserve pit. Should suspected sour gas be vented through the flair line, a flare pistol will be used to ignite the flare.
- C. Protective equipment for essential personnel will be installed and maintained as follows:
1. 30-minute air packs will be maintained on the rig floor and near the briefing area.
  2. 30-minute work units will be maintained at the H2S trailer and/or on the rig floor.
  3. 30-minute escape units will be maintained on the rig floor.
  4. 300 cu.ft. air cylinders will be maintained in the H2S trailer.
  5. Associated breathing air equipment will also be installed and maintained.
  6. Hydrogen sulfide monitor will be located in the dog house on the rig floor with sensors placed on the rig floor, at the bell nipple, the shale shaker, and in the pit area.
  7. An audible/visual alarm will be located near the dog house on the rig floor.