

Gray

Operator Mallen Oil Company
 Well Mallen '16' State #11
 Unit F Section 16 Township 24 Range 26
 API # 30-015-29399

TOPS

Balade	~ 300'	*
Base Salt	~ 146'	*
Lamar LS	1610'	
Delaware Sd	1822'	*
Bone Spring	5280'	*

← Plug 60'-0" Surf.

← Shoe Plug 562'-800' TAG.

← Plug 1800' — TAG

← Plug 2755' TAG

← CIBF @ 3310' Need 35' Cement on Top.

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

9 5/8" CSG
 512'
 CMT. Circ

Perfs - 2755'-2778'
 3402'-3420'
 5004'-5020'

CSG 5 1/2"
 5400' TD
 CMT. Circ

PL