

Operator Mallon Oil Company
 Well Landi '15' Federal #1
 Unit C Section 15 Township 24 Range 29
 API # 30-015-29764

TOPS

Salado	630'	*
Base Salt	1378'	*
Lamar LS	1704'	*
Delaware Sd	1868'	*
Base Spring	5254'	*

← Plug 60' - 0' Surf.

← Shoe Plug 630' - 452' TAG

← Plug 1478' TAG

← Plug 1868'

← Plug 2702' TAG

← CIBP @ 4850' Add 35' cement

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

9 5/8" CSG
 502'
 C.M.T. Circ.

Perf 4916' - 9928'
 4552' - 4586'
 3552' - 3586'
 2752' - 2774'

5 1/2" CSG
 5400' TO
 C.M.T. Circ.

[Handwritten signature]