

Operator Concho Resources Inc.
Well Indian Draw 12' Fed! #1
Unit I Section 12 Township 22 Range 27
API # 30-015-30052

TOPS

Salade	336'
Base Salt	1920'
Lamer	2220'
Delaware Sd	2327'
Base Spring	5670'
Wolfcamp	9162'
Penn	~ 9700'
Strawn	10642'
Atoka	10982'
Moore Limestone	~ 11300'
Moore Clastics	11595'
Barnett	12200'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.