

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

LEASE DESIGNATION AND SERIAL NO.

NM-0558669

INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER Dry hole		7. UNIT AGREEMENT NAME Black River Unit	
2. NAME OF OPERATOR Monsanto Company		8. FARM OR LEASE NAME	
3. ADDRESS OF OPERATOR 101 N. Marlenfeld, Midland, Texas 79701		9. WELL NO. 1	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1325' FNL & 1980' FEL		10. FIELD AND POOL, OR WILDCAT Wildcat	
14. PERMIT NO. 30-018-20228		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 3, T-26S, R-23E	
15. ELEVATIONS (Show whether DF, RT, OR, etc.)		12. COUNTY OR PARISH Eddy	
		13. STATE New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PUMP OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☒

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Drilled to total depth of 8151' and logged. Well was a dry hole. Verbal approval to plug and abandon was received from Mr. James Knauf on 7-9-69.

Hole was filled w/10" mud and cement plugs were set as follows:

30 ex 7350' - 7450'; 30 ex 6650' - 6650'; 30 ex 6000' - 6100';

30 ex 5000' - 5100'; 35 ex 500' - 700'. Job complete 7-10-69

Well was turned to ~~United States Dept. of Interior Bureau of Land Management~~ at this point for completion as a water well. USGS will be notified when location is cleaned up & ready for inspection. 4" pipe dry hole marker w/location shown thereon was placed adjacent to surface pipe.

RECEIVED
JUL 17 1969
U. S. GEOLOGICAL SURVEY
NATIONAL CENTER

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE **Engineer**DATE **7-16-69**

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

NGV - 3 1969

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.