

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: September 30, 1990

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

RECEIVED

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other Gas Storage Well

2. Name of Operator

El Paso Natural Gas Co.

3. Address and Telephone No.

P. O. Box 1492, El Paso, Texas 79978 (915) 541-2600

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

2080 FSL & 660 FEL, Sec. 33, T-25-S, R-24-E

5. Lease Designation and Serial No.

Federal NM 22207

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

WASHINGTON RANCH STORME
W.L. NO. 3 PROJECT

9. API Well No.

30-015-20569

10. Field and Pool, or Exploratory Area

11. County or Parish, State

Eddy Co, N.M.

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection

Replace Pkr. & Cement behind production csg.

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Move in & rig up pulling unit and surface equipment
- 2) Pump necessary fluid to kill well
- 3) Remove wellhead & install BOP
- 4) Release pkr. & pull out of the hole w/production tubing & inspect
- 5) Rig up wireline truck & run gauge ring & junk basket
- 6) Retrieve packer & lay down workstring
- 7) Run bridge plug & set below bottom of surface casing
- 8) Run perforating gun & perforate production casing below bottom of surface casing
- 9) Pump cement and circulate to surface
- 10) Wait on cement
- 11) Run bit & drill collars & drill out cement
- 12) Pressure test production casing
- 13) Run Casing Bond Log to verify good cement job
- 14) Retrieve bridge plug & lay down work string

- 15) Test in hole w/seal assembly & production tubing
- 16) Run in w/Baker Model D pkr. w/plug in place
- 17) Run packer & set above perforations
- 18) Swab well down to equilibrate
- 19) Rig up wireline & fish plug out of packer
- 20) Flow well to clean up
- 21) Return well to service

14. I hereby certify that the foregoing is true and correct

Signed

Title Regional Reservoir Engineer

Date 3/4/91

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See instruction on Reverse Side