- CORRAL DRAW UF #1
- (162) 14,419 ND, strung back blks from 10 lines to 8 lines, ran 6" HTC OWC bit on 27 4-3/4 DC's, 3½ & 4½ DP to 7000, cont to run DP, prep to drill 6" hole.
  - CORRAL DRAW UT #1
  - 6/12 (163) 14,429 drlg lm, 6" hole, NND, 9.5# Br Wtr. drld LC, FC & cmt to 14,414, now POH w/ bit.
    - CORRAL DRAW UT #1
  - 6/13 (164) 14,441 drlg sd & sh, 6" hole, NND. 9.5# Br Wtr.
    - CORRAI, DRAW UT #1
  - 6/14 (165) 14,466 drlg sd & sh, 6" hole, NND. 9.5# Br Wtr.
    - CORRAL DRAW UT #1
  - 6/15 (166) 14,624 drlg sh, 6" hole, NND. 9.5# Br Wtr.
  - 6/16 (167) 14,705 drlg sh, 6" hole, NND. 9.5# Br Wtr. POH, look for hole in DP, hole in 4-1/2" DP @ 7500'.
  - 6/17 (168) 14,932 drlg sh, 6" hole, NND. 9.5# Br Wtr.
    - CORRAL DRAW UT #1
  - 6/18 (169) 14,972 drlg sh & lm, 5-7/8" hole, 10° 14,950. 9.6# Br Wtr. Reduced hole from 6" to 5-7/8" @ 14,965'.
    - CORRAL DRAW UT #1
- 6/19 (170) 15,074 drlg lm & sh, 5-7/8" hole, NND, 9.6# Br Wtr. down 2 hrs for rprs.
  - CORRAL DRAW UT #1
  - 6/20 (171) 15,164 drlg lm & sh, 5-7/8" hole, NND. 9.6# Br Wtr. Down 3-1/2 hrs for rig repairs.
    - CORRAL DRAW UT #1
  - 6/21 (172) 15,196 drlg lm, sh & tr of ch, 5-7/8" hole, NND. 9.6# Br Wtr.

    CORRAL DRAW UT #1
  - 6/22 (173) 15,325 drlg sh, 5-7/8" hole, NND. 9.6# Br Wtr.
  - 6/23 (174) 15,560 ND lm & ch, 5-7/8" hole, NND. 9.5# Br Wtr. started out of hole, stuck drlg string w/ bit @ 15,545, working stuck pipe past 4 hrs w/ full circ, prep to spot pipe lax w/ oil.
  - 6/24 (175) 15,560 ND lm, ch, tr of dolo, 5-7/8" hole, 9.4# Br Wtr. spotted 40 gals pipe lax in 35 bbls oil thru bit & around DC's, drlg string come loose in 3-3/4 hrs, POH, LD 24 jts 4½ DP, clean all pits, now GIH w/ Bit #25, down total 14-3/4 hrs, stuck drlg string.
    - CORRAL DRAW UT #1
- 6/25 (176) 15,585 ND dolo & lm, 5-7/8" hole, NND, 9.3# Br Wtr. reamed 23' in 1 nr, circ 4 nrs, POH, WO Howco 3½ hrs for crossover for test tool, prep to test Dev 15,440-15,585/145'.