

Form 5-371
May 1963UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN
(Other instructions
reverse side)Form 5-371
Budget Item 15-9999-1000

SUNDRY NOTICES AND REPORTS

(Do not use this form for proposals to drill or to deepen or plug back to a different depth. Use "APPLICATION FOR PERMIT" for such proposals.)

RECEIVED

MAY 03 1977

U.S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

NM 13081

6. IS INDIAN, ALIEN, OR FOREIGN NAME

FEB 26 1979

D.C.C.
ARTESIA, OFFICE1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Leland A. Hodges, Trustee

3. ADDRESS OF OPERATOR

P. O. Box 3400, Albuquerque, NM 87110

4. LOCATION OF WELL (Report location clearly and in accordance with any state requirements. See also space 17 below.)
At surface

1700' FSL & 2200' FWL of Section 4, 26S., 25E.

14. PERMIT NO.

30-815-22119

15. ELEVATIONS (Show whether OF, RT, GR, etc.)

GR 3734 KB 3739

4-26S.-25E.

12. COUNTY OR PARISH 13. STATE

Eddy

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

SURFACE CASING

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

X

X

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

4-14-77 spudded well

4-15-77 TD 201' Ran 201 8 5/8" 28# used casing, cemented w/75 sack Class C w/4% calcium Chloride Plugged down 11:15 p.m.

4-18-77 WOC 61 hrs., Tested casing to 600#. Held OK

4-27-77 TD 1675'. Ran CNL density log. Mixed plugging mud to U.S.G.S. specs. Set 20 sack cement plug from 1538 to 1638, set 30 sack plug from 151 to 251, and set 10 sack cement plug in top of surface casing. Abandoned location for subsequent leveling and restoration after pits have dried.

18. I hereby certify that the foregoing is true and correct

SIGNED

Ben Dwyer

TITLE

Geologist

DATE

5-2-77

(This space for Federal or State office use)

APPROVED BY

Lee S. Lara

TITLE

ACTING DISTRICT ENGINEER

DATE

FEB 23 1979

CONDITIONS OF APPROVAL, IF ANY: