

- 10/30/79 Tagged TOC @ 29' - 12 HR CITP 50# - Drilled cement stringers to 50' + fell thru to 250'
- 10/31/79 Drilled from 250-502' (cement stringers) Picked up a gas kick @ 502' when bit fell thru. 12 HR CITP before drilling @ 250' was 250#
- 11/1/79 12 HR CITP 500# ran tbg to 1525 without tagging anything gas + wtr flow increasing. Mudded hole up w/ 12# mud
- 11/2/79 12 HR CITP 50# - Ran tbg to 1840 + tagged plug Drilled stringers to 1997 + had a good gas kick. ISIP 800#
- 11/3/79 12 HR CITP 375# - Drilled stringers to 2136 fell thru + ran bit to 3232' drlg firm cement from 3232 to 3242
- 11/5/79 36 HR CITP 50# - Circ hole w/ mud from 3232' - Tripped tbg Run tbg OE to 2613' + pumped 50 sx Class C w/ 4% CC Calc Top 2482' Tagged TOC @ 2529 Pulled Tbg to 1962 + pumped 100 sx Class C
- 11/6/79 0# Pressure Tagged TOC @ 1802 Set CIP Be 1306 w/ 15 SX Cap Spotted 37 sx @ 350'