

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

AUG 27 1992

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: September 30, 1990

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well ☐ Oil Well ☐ Gas Well ☒ Other Gas Storage Well	5. Lease Designation and Serial No. Fed. NM-22207
2. Name of Operator El Paso Natural Gas Co.	6. If Indian, Allottee or Tribe Name
3. Address and Telephone No. P.O. Box 1492, El Paso, Texas 79978 (915) 541-2600	7. If Unit or CA, Agreement Designation
4. Location of Well (Fossage, Sec., T., R., M., or Survey Description) 1045' FWL & 2363' FNL SEC. 34, T-25-S, R-24-E	8. Well Name and No. W.I. #17
	9. API Well No.
	10. Field and Pool, or Exploratory Area Wsh. Rnch Mor.
	11. County or Parish, State Eddy Co., N.M.

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
☒ Notice of Lease	☐ Abandonment
☐ Subsequent Report	☐ Recompletion
☐ Final Abandonment Notice	☐ Plugging Back
	☐ Casing Repair
	☐ Altering Casing
	☒ Other
	Inspect and Cement

(Note: Report results of multiple completions on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent data, including estimated date of starting any proposed work. If well is permanently drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- | | |
|---|--------------------------------|
| 1) MI & RU PU & Surface Equipment | 13) Run Bit & Drill Collars |
| 2) RU WL (Run GR, JB & Set Plug in Pkr) | & Drill Out Cement |
| 3) Load Tbg, Remove WH & Install BOP | 14) Pressure-Test Prod Csg |
| 4) Release Tbg & POOH & Inspect | 15) Run Cement Bond Log |
| 5) Run CBL and Tag TOC | 16) Retrieve BP & Lay Down |
| 6) Run Casing Inspection Log | Work String |
| 7) Run BP & Set Below TOC | 17) Test In-Hole w/Seal |
| 8) Run Perf Gun & Perf Prod Csg | Assembly & Prod Tbg |
| 9) Run Prod Pkr & Set Above Perfs | 18) Fill Annulus w/Pkr Fluid |
| 10) Pump Cement & Circ to Surface | 19) Swab Well to Equalize |
| 11) Wait on Cement | 20) RU WL & Fish Plug from Pkr |
| 12) Retrieve Prod Pkr & Lay Down | 21) Flow Well to Clean-up |
| Work String | 22) Return Well to Service |

14. I hereby certify that the foregoing is true and correct.	Reservoir Engineer	7/17/92
Signed <u>David J. Brewster</u>	Title <u>JB</u>	Date <u>1992</u>
(This space for Federal or State office use)		
Approval by _____	Title _____	Date _____
Continuation of approval, if any.		