

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

NM OIL CONS. COMMISSION  
Drawer DD  
Alameda, NM 88210

FEB 11 11 05 AM '93

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires September 30, 1990

3. Lease Designation and Serial No.  
NM-22207

6. If Indiv. Allotment or Tribal Name

7. If Unit or Co. Agreement Designation

8. Well Name and No.

W.I. #19

9. API Well No.

10. Field and Pool, or Exploratory Area  
Wsh. Rnch Mor.

11. County or Parish, State  
Eddy Co., N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other

Gas Storage Well

2. Name of Operator

El Paso Natural Gas Co.

3. Address and Telephone No.

P.O. Box 1492, El Paso, Texas 79978 (915) 541-2600

4. Location of Well (Feetage, Sec., T., R., M., or Survey Description)

687' FNL & 2017' FWL  
SEC. 34, T-25-S, R-24-E

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☒ Altering Casing  
☐ Other
- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection
- Inspect and Cement

(From: Report results of multiple completion on Well Completion or  
Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent data, including estimated date of starting any proposed work. If well is permanently closed, give subsurface locations and measured and true vertical depths for all markers and other pertinent to the work.)

- |                                         |                                |
|-----------------------------------------|--------------------------------|
| 1) MI & RU PU & Surface Equipment       | 13) Run Bit & Drill Collars    |
| 2) RU WL (Run GR, JB & Set Plug in Pkr) | & Drill Out Ret. & Cement      |
| 3) Load Tbg, Remove WH & Install BOP    | 14) Pressure-Test Prod Csg     |
| 4) Release Tbg & POOH & Inspect         | 15) Run Cement Bond Log        |
| 5) Run CBL and Tag TOC                  | 16) Retrieve BP & Lay Down     |
| 6) Run Casing Inspection Log            | Work String                    |
| 7) Run BP & Set Below TOC               | 17) Test In-Hole w/Seal        |
| 8) Run Perf Gun & Perf Prod Csg         | Assembly & Prod Tbg            |
| 9) Run Cement Ret. & Set Above Perfs    | 18) Fill Annulus w/Pkr Fluid   |
| 10) Pump Cement & Circ to Surface       | 19) Swab Well to Equalize      |
| 11) Wait on Cement                      | 20) RU WL & Fish Plug from Pkr |
| 12) Sting out of Cement Ret. & Lay Down | 21) Flow Well to Clean-up      |
| Work String                             | 22) Return Well to Service     |

14. I hereby certify that the foregoing is true and correct

Reservoir Engineer

2/04/93

Signature David J. Brewster

Title

Date

(This space for Federal or State office use)

Approved by

Title

Date

2-17-93

**W.I. FEDERAL # 19**  
(Current Wellbore)

Location:  
Sec 34, T-25S, R-24E  
Eddy County, New Mexico

