

2. Pull tubing to 60' and spot plug to surface. Pull tubing.
3. Cut 12 3/4" casing at least 3' below ground level. Weld plate on top.
4. Weld on dry hole marker.
5. Clean location and move off.