

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN (PLICATE)
(Other last
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM-24777

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.

Use "APPLICATION FOR PERMIT-" for such proposals.

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

J.C. Williamson

3. ADDRESS OF OPERATOR

P.O. Box 16 Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

710' FSL & 660' FWL

CARL
AREA

RECEIVED

DEC 15 '88

O. C. D.
ARTESIA OFFICE

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Ingram-Grooms Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

East Brushy Draw

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 9, T-26-S, R-30-E

14. PERMIT NO.

30-015-24978

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3076' GR

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Set CIBP @ 5500'±, put 10' cement on top of plug.
 - 2) Shot off 5½" casing @ 4200'± (TOC 4300'), pull and lay down same.
 - 3) Set stub plug 50' in and out of stub of 5½" casing.
 - 4) Tag plug, reset if not holding.
 - 5) Set 100' plug across shoe of 8-5/8" casing (shoe of casing @ 3352').
 - 6) Tag plug. Reset if not holding.
 - 7) Shoot off and pull 8-5/8" @ 3000', pull and lay down same.
 - 8) Set 100' stub plug at point 8-5/8" is shot off.
 - 9) Tag plug, reset if not holding.
 - 10) Set 150' cement plug from 835-985', across shoe of 13-3/8" casing @ 885' and across top of rustler formation.
 - 11) Tag plug, reset if not holding.
 - 12) Set 50' surface plug, erect dry hole marker, clean location.
- Note: hole is to be filled with 98± mud.

Work to commence Wednesday December 7, 1988 as per conversation Shannon Shaw @ BLM.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Engineer

DATE

12-05-88

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

12-14-88

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side