

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☒ gas well ☐ other ☐ SEP 09 '88
2. NAME OF OPERATOR
Fuller Petroleum, Inc. ✓ O. C. D.
ARTESIA, OFFICE 76102
3. ADDRESS OF OPERATOR
2020 Texas American Bank Bldg., Ft. Worth, Tx
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 1650' FNL & 1685' FWL
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>	<input type="checkbox"/>
(other)		

5. LEASE
LC-061497
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
- - -
7. UNIT AGREEMENT NAME
- - -
8. FARM OR LEASE NAME
Gulf Federal
9. WELL NO.
2
10. FIELD OR WILDCAT NAME
Brushy Draw-Delaware
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec 13-T26S-R29E
12. COUNTY OR PARISH
Eddy
13. STATE
New Mexico
14. API NO.
- - -
15. ELEVATIONS (SHOW DF, KDB, AND WD)
3014' GR.

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to:

- | | |
|---|--|
| 1. Set CIBP @ \pm 5,200' (Top perms 5,263'). | 11. Tag cement. |
| 2. Dump 35' of cement on CIBP. | 12. Spot 50' cement plug, 50' to surface. |
| 3. Load hole with 10.00# mud. | 13. Cut off surface pipe 3' below surface. |
| 4. Shoot off pipe @ freepoint (TOC 2,850'). | 14. Install 4" marker-4' above GR. |
| 5. POOH - LD pipe. | |
| 6. Spot 150' cement. (75' in stub & and 75' above stub). | |
| 7. Tag cement. | |
| 8. Spot 100' cement plug-1600'-1500'. | |
| 9. Tag cement. | |
| 10. Spot 100' Cement at shoe (945'), 50' out and 50' above shoe-995' to 895'. | |

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED C. W. Downey, Jr. TITLE Operations Mgr. DATE August 22, 1988

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE 9-7-88
CONDITIONS OF APPROVAL, IF ANY: