

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

10010 1992

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well <input checked="" type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other	5. Lease Designation and Serial No. NM-55929
2. Name of Operator Bettis, Boyle & Stovall	6. If Indian, Allottee or Tribe Name
3. Address and Telephone No. P. O. Box 1240, Graham, TX 76450 817-549-0780	7. If Unit or CA, Agreement Designation
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 660' FNL & 860' FEL of Se. 08, T25S, R29E Unit Letter A	8. Well Name and No. Exxon "8" Federal #1
	9. API Well No. 300152589400
	10. Field and Pool, or Exploratory Area Wildcat (Bone Springs)
	11. County or Parish, State Eddy Co., NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input checked="" type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Procedure to recomplete from Morrow/Atoka to Bone Springs Sand:

1. Set 7-5/8" CIBP @ 12,000'.
2. Spot 100' cement plug from 11,900-12,000'.
3. Spot 200' cement plug from 9685-9885' (100' in & out of top of liner).
4. Perf Bone Spring @ 9005-9030'.
5. Swab test well & evaluate for stimulation if necessary.

14. I hereby certify that the foregoing is true and correct

Signed Kim Ligon Title Production Analyst Date 7/30/92

(This space for Federal or State office use)

Approved by _____ Title _____ Date 8/4/92
Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side